

HD SH Custom Flow Control Valve for Showers

Installation Instructions

The Flow Control Valve for Showers with a National Sanitation Foundation (NSF) Certified Washer is easily installed.

View installation video @ <http://www.watermiser.com/installation-instructions>

1. Detach showerhead from post or if it is a handheld shower, detach hose from the post on the wall. ***
2. Run water to clear debris from supply line.
3. Check the FCV washer to ensure it is fully seated in the FCV.
4. Wrap plumbers tape around the thread of the post.
5. Attach the Custom Flow Control Valve to the post and tighten.
6. Ensure the Flow Control Valve is installed tightly and securely. Be sure not to over tighten.
7. Attach the showerhead or shower supply line to the Custom Flow Control Valve already attached to the post by screwing it onto the thread of the FCV and tighten.
8. Check for leaks. (tighten or add plumbing tape until leak subsides)
9. Your Shower is now ready for use.

***Make sure to install the flow control valve between the wall post and the back end of the shower hose.

